


OBSBOT Tail Air Smart Remote Controller User Manual

Parts Info



- 01. **【Multi-screen Mode】** Picture-in-Picture Switching
* Requires use with OBSBOT Talent or Obsbot Live APP.
- 02. **【ON/OFF】** Long press to turn on/off Tail Air
- 03. Status Indicator
- 04. **【Focus/Camera】** Half-press to focus, press to take a photo
- 05. **【Record】** Start/End recording
- 06. **【Gimbal Control】** Up/Down/Left/Right
* Click to restore to the initial position, long press to enable gyroscope.
- 07. **【Human Tracking】** Enable/Disable human tracking
- 08. **【Animal Tracking】** Enable/Disable animal tracking
- 09. **【Laser Close-up】** Hold to enable the laser, and double-click to execute or exit AI laser Close-up
* Note: The laser cannot irradiate the eyes, it will cause serious eye damage.
- 10. **【Preset Position】** Click to go to preset position P1/P2/P3, long press to add/update
- 11. **【Select Camera】** Select Camera 1/2/3
Click: Switch camera control (green light)
Double-click: Output camera video stream (red light)
* Double-click function requires use with OBSBOT Talent or Obsbot Live APP.

Button Backlight	Description
Solid white light	Tail Air connected
Solid green light	Controlling the current Tail Air
Solid red light	Current Tail Air is outputting
Light off	Tail Air not connected
* If control and output are the same device, the red light will be solid	


12. **【Custom】** Customize button functions
 - * Set button functions through the Obsbot Start APP.
13. USB-C Port - - Power Input
14. **【Zoom】** T - Zoom in; W - Zoom out
15. **【Lock Button】** Toggle up to disable all function keys, toggle down to enable all function keys

Before You Use

Step 1

Turn on Tail Air and quickly click the Tail Air power button 3 times. The Tail Air status indicator will change to blue flashing.

Step 2

Hold the Remote Controller  + **【1】**/**【2】**/**【3】** dual keys for 3 seconds. The Remote Controller indicator light changes from solid to continuous flashing.

Step 3

a) Remote Controller connected to first Tail Air

After the Remote Controller indicator flashes quickly 3 times and goes out, the corresponding keys **【1】** / **【2】** / **【3】** will have a steady green light, indicating successful pairing.

b) Remote Controller connected to second/third Tail Air

After the Remote Controller indicator flashes quickly 3 times and goes out, the corresponding keys **【1】** / **【2】** / **【3】** will have a steady white light, indicating successful pairing.

* Note: During the Remote Controller update, the status indicator will flash red and blue alternately.